

Download on a PC with a PC Card reader

General Procedure

WARNING

You must use STEP#1 and STEP#2 for modules Ver00.03, Ver00.04, Ver00.05, Ver00.06.

You must use ONLY STEP#2 (and not STEP1) for modules Ver00.07

Tool used for the update

- PC with
 - Windows 95 Or Windows 98
- Software
 - ◆ Create a new directory : C:\update, where you put the following files :
 - Ird112.bin
 - Ird113.bin
 - Xaload11.exe
 - ◆ Directory : c:\windows\inf where you put the following files :
 - Irdet095.inf (For Windows 95)
 - Irdet098.inf (For Windows 98)

Update procedure

For modules Ver 00.03, Ver 00.04, Ver 00.05, Ver 00.06.

STEP#1

- Start a MS-DOS session.
- type "cd C:\update"
- type "xaload11 ird112.bin"
- Follow the instruction on the screen:
- insert the module when it is asked, wait for the beep and then press the space bar
- the bloc counter will remain about few seconds on value 3, then it will run up to the maximum value and will remain about 10 seconds on the maximum value
- UPDATE SUCCESSFULL will be displayed: the update is finished, type Q and then remove the module.

STEP#2

Then still under a MS-DOS session and the C:\update directory :

- type "xaload11 ird113.bin"
- Follow the instruction on the screen:
- insert the module when it is asked, wait for the beep and then press the space bar
- the bloc counter will remain about 10 seconds on value 2, then it will run up to the maximum value and will remain about 10 seconds on the maximum value
- UPDATE SUCCESSFULL will be displayed : the update is finished, type Q and then remove the module.

Your module is now updated with the 0.07B Irdet0 version.

For modules Ver 00.07.

STEP#2

Then still under a MS-DOS session and the C:\update directory :

- type "xaload11 ird113.bin"
- Follow the instruction on the screen:
- insert the module when it is asked, wait for the beep and then press the space bar
- the bloc counter will remain about 10 seconds on value 2, then it will run up to the maximum value and will remain about 10 seconds on the maximum value
- UPDATE SUCCESSFULL will be displayed : the update is finished, type Q and then remove the module.

Your module is now updated with the 0.07B Irdeto version.